




TAPPI INTERCAMBIABILI



INTERCAMBIABILI HASCO	T	D	L	L1
RRTRIH06	M3	6	8	11.5
RRTRIH08	M4	8	8	11.5
RRTRIH10	M6	10	10	14
RRTRIH12	M6	12	10	14
RRTRIH15	M8	15	15	16
RRTRIH16	M8	16	16	16
RRTRIH20	M8	20	20	16



INTERCAMBIABILI DME	D	L
RRTRID06	6	10
RRTRID07	7	
RRTRID08	8	
RRTRID085	8.5	
RRTRID10	10	
RRTRID115	11.5	
RRTRID12	12	
RRTRID14	14	12
RRTRID15	15	
RRTRID16	16	
RRTRID20	20	
RRTRID22	22	